



Wireless Supercharger & Bluetooth Speaker

(with Alarm Clock)



INSTRUCTION MANUAL

WHAT'S INCLUDED:

- 1 X Bluetooth Speaker
- 1 X USB to Micro-USB Charging cable
- 1 X Instruction manual

BLUETOOTH PARING INSTRUCTION:

(Note: The Bluetooth code is Figgers Wireless Charger, pair code:0000)

- 1.Keep the distance between the phone and speaker within 10 meters. (for pairing only)
- 2.Press and hold the round power button for 2 seconds to power on, hear the prompt sound, the display turns on.
- 3.Turn on the Bluetooth function on the mobile device, search for Bluetooth devices, and select "Figgers Wireless Charger".
- 4.If you are prompted to enter a password to complete pairing (Note: some mobile phone can be connected directly without entering pairing code), enter "0000".
- 5.The Figgers Wireless Charger will connect to your device and you will hear "paired".
- 6.It is ready for use.
*Speaker will automatically be paired if the mobile device has been paired before.
- 7.Press and hold power button for 4 seconds to power off.
*Press and hold "pause" button for 2 seconds can disconnect the Bluetooth connection.

WIRELESS CHARGING FUNCTION:

- Connect to the power supply 5V/2A by micro USB cable, the red LED light in the USB port will on.
- Put your mobile phone which supports wireless charging on the top of the center charging area.
- It starts to be charged and will show battery volume on your phone during charging.

SPEAKER CONTROLS:

PLAY/PAUSE/ANSWER/REFUSE THE CALL

Press “pause (MFB)” button to answer the call, press it again to hang up. Press and hold “pause (MFB)” button to refuse the call. Double press “pause (MFB)” button to call back the last number.

MUSIC/VOLUME

During a call or when listening to music

Volume + Press and hold “+” button

Volume - Press and hold “-” button

Go to next song Short-press “+” button

Go to previous song Short-press “-” button

SYMBOL

 Power Button

 CLOCK Clock Button

 Volume +/Next song

 Volume -/Previous song

 Play/Pause Button

ALARM CLOCK FUNCTION:

EDIT CLOCK TIME

HOUR EDIT: Double-press Clock button to enter editor interface. Press “+” or “-” to Adjust hour.

MINUTE EDIT: After hour edit, short-press Clock button to switch to minute edit. Press “+” or “-” to Adjust minute.

Short-press Clock button to confirm and exit edit mode. No operation for 5 seconds will automatically confirm and exit.

ALARM CLOCK SETTING

Alarm Clock 1: Press and hold Clock button for 2 seconds to enter alarm setting interface. After the display showed “ALA1”, short-press “+” or “-” to switch on/off the 1st alarm. Press the clock button then press “+” or “-” to adjust hour, short-press the clock button again to switch to minute. Press “+” or “-” to adjust minute. No operation 5 seconds will automatically confirm and exit.

ALARM CLOCK RINGS

When the time runs to the alarm clock setting time, the alarm bell rings for 30 minutes.

Short-press the “clock” button to stop the alarm;

Snooze mode: Short-press “Power” button, the alarm will ring again in 9 minutes later.

Alarm Clock 2: After alarm1 setting confirmed, short-press Clock button to switch to alarm 2 “ALA2” setting. The operation method is the same as alarm1.

CHARGING THE BLUETOOTH SPEAKER:

(Be sure to fully charge the speaker before using for the first time.)

- Plug the standard USB charging cable into the speaker and a powered USB port.
- The LED light is red when charging. The light will turn off when the battery is fully charged.

Remark:

1. The Bluetooth speaker can be used during charging.
2. The LED flash red quickly and there is prompt sound when it is a low battery.
3. Please use the offered 2A cable to charge the speaker.

SPECIFICATIONS:

- Bluetooth Version: V5.0
- Power out: 3W*2 4Ω
- Built-in battery: 2000mAh
- Charging time: up to 4.5 hours
- Playing time: up to 7 hours

SCAN ME



Figgers.com
Figgers Communication Inc
3810 Inverrary Blvd Suite: 401
Fort Lauderdale FL 33319-4359
United States